



Pro Barre Upright / Foot Assembly Notice.

## PLEASE READ BEFORE ASSEMBLY

Notice: When inserting the upright bar into the foot assembly clamp, make certain that the head of the draw bolt is positioned in the center of the bar as shown below. Once the bar is fully seated in the clamp you can then securely tighten clamp.

